

Multifunctional LED light

en Instructions for use

Safety warnings

Read the safety warnings carefully and only use the product as described in these instructions to avoid accidental injury or damage. Keep these instructions for future reference. If you give this product to another person, remember to also include these instructions.

Intended use

The multifunctional LED light is intended for use in dry indoor rooms as a visual aid to help with orientation when it is dark. It is only intended for use in private homes and is not suitable for commercial use.

Danger to children

- Keep the packaging materials out of the reach of children. They pose several risks, including the risk of suffocation!
- The product is not a toy. Children are not aware of the risks involved in handling electronic products incorrectly. Therefore, keep children away from the product.
- Swallowing single-use/rechargeable batteries can be fatal. If a single-use/rechargeable battery has been swallowed, this can lead to severe internal chemical burns and even death within 2 hours. Therefore, keep both new and old single-use/rechargeable batteries and the product out of the reach of children. If you think that a single-use/rechargeable battery has been swallowed or has got into the body in any other way, seek medical advice immediately.

Risk of injury

- Do not look directly into the light for long periods. This could impair eyesight.
- Single-use batteries must not be charged, taken apart, thrown into fire or short-circuited.
- If a battery has leaked, avoid all contact with your skin, eyes and mucous membranes. Rinse the affected areas with water and consult a doctor immediately.

Material damage

- Protect the batteries from intense heat. Remove the batteries from the product when they are flat or if you do not intend to use the product for a prolonged period. This will help prevent damage caused by leakage.
- Always replace all batteries at the same time. Do not mix old and new batteries, different types or brands of batteries, or batteries with different capacities.
- If necessary, clean the battery and appliance contacts before inserting the batteries. Risk of overheating!
- Ensure correct polarity (+/-) when inserting the batteries.
- Protect the product from dust, moisture, direct sunlight and extreme temperatures. Avoid extreme knocks and impacts.
- The built-in LEDs cannot and must not be replaced.
- Keep cards with magnetic strips, such as credit cards, debit cards, etc. away from the magnetic mounting. The magnetic strips could be damaged. Also keep magnetic storage media and all devices affected by magnetism or which could suffer functional impairment away from the magnetic mounting.
- To enable the magnetic mounting with the tesa® adhesive strip to stick well at the desired location, the surface there must be dry and free of dust, grease, silicone and limescale. In addition, the surface must be solid, smooth and have the necessary load-bearing capacity. Uneven and porous surfaces are not suitable.
- The tesa® adhesive strip is designed for single use only. Constant temperatures over 40 °C reduce the hold of the tesa® adhesive strip. The tesa® adhesive strip is not suitable for temperatures below 15 °C.
- The tesa® adhesive strip only reaches its full hold after approx. 24 hours. Do not load the magnetic mounting before this.

- Mount the magnetic mounting in such a way that nothing will be damaged if the multifunctional LED light should fall down.
- When you remove the magnetic mounting, some adhesive residue may remain on the surface. However, in most cases this can be easily removed from suitable, smooth surfaces by rubbing it off with your finger. Bear in mind that on painted surfaces the colour may be removed as well!
- Do not use any caustic, aggressive or abrasive products for cleaning.


Technical specifications

Model:	671 978
Single-use batteries:	3x LR6 (AA)/1.5 V
Protection class:	III 
Detection angle:	approx. 110°
Sensor range:	approx. 3 m
Light duration:	approx. 30 seconds
Ambient temperature:	+10 to +40 °C
Made exclusively for:	Tchibo GmbH, Überseering 18, 22297 Hamburg, Germany

In the course of product improvements, we reserve the right to make technical and optical modifications to the product.




Inserting / replacing the batteries




Mounting the LED light

You can attach the magnetic mounting simply with the tesa® adhesive strip or with the screws provided.

Sticking in place




Screwing in place




Adjusting the angle of the LED light


You can rotate the multifunctional LED light up to 90°. Adjust the light so that it lights up the selected area well.



The multifunctional LED light has a motion sensor. You can rotate the motion sensor up to 180°.




Depending on how far to the front or to the back you have turned the motion sensor, it can detect movement within a 3 m distance and at an angle of 110°, which will then switch the LED light on.



Tip: If you remove the LED light from the magnetic mounting, you can also use it as a torch.

Switching on and off



- ON** = The LEDs are permanently switched on.
- AUTO** = The LEDs light up for approx. 30 seconds and then switch off automatically if the motion sensor does not detect any movement. As soon as the motion sensor detects further movement, the LEDs will light up again for approx. 30 seconds.
- OFF** = The LEDs are permanently switched off.

Disposal

The product, its packaging and the supplied batteries have been manufactured from valuable materials that can be recycled. Recycling reduces the amount of refuse and preserves the environment.

Dispose of the **packaging** at a recycling point that sorts materials by type. Make use of the local facilities provided for collecting paper, cardboard and lightweight packaging.



Appliances, single-use batteries and rechargeable batteries marked with this symbol must not be disposed of along with household waste!

You are legally obliged to dispose of old appliances separately from household waste. Electronic appliances contain hazardous substances and, if stored or disposed of improperly, may cause harm to health and the environment. Information about collection points where old appliances can be disposed of free of charge is available from your local authorities.

Flat **single-use** and **rechargeable batteries** must be handed in at a local authority collection point or returned to a battery retailer.

Tape off the contacts of lithium single-use/rechargeable batteries prior to disposal.



www.tchibo.de/instructions
(Please enter the product number in the box labelled "Bedienungsanleitungssuche" and click on "Suchen".)

Product number: 671 978

Made exclusively for:
Tchibo GmbH, Überseering 18, 22297 Hamburg, Germany

Çok fonksiyonlu LED lamba

tr Kullanım Kılavuzu

Güvenlik uyarıları



Güvenlik uyarılarını dikkatle okuyun. Kaza sonucu ortaya çıkabilecek yaralanmalar ve hasarları önlemek için ürünü yalnızca bu kullanım kılavuzunda belirtildiği şekilde kullanın. Gerekliğinde tekrar okumak üzere bu kılavuzu saklayın. Bu ürün başkasına devredildiğinde, bu kılavuz da beraberinde verilmelidir.

Kullanım amacı

Çok fonksiyonlu LED lamba, kuru iç mekanlarda aydınlatma ve yön bulmaya yardımcı olması amacıyla tasarlanmıştır. Sadece ev içi kullanım için tasarlanmıştır ve ticari kullanım için uygun değildir.

Çocuklar için Tehlike

- Çocukları ambalaj malzemesinden uzak tutun. Aksi takdirde boğulma tehlikesi vardır!
- Ürün oyuncak değildir. Çocuklar, elektrikli cihazların hatalı kullanılması sonucu oluşabilecek tehlikeleri fark edemez. Bu nedenle çocukları üründen uzak tutun.
- Piller/Şarjlı piller yutulduğunda hayati tehlike oluşabilir. Bir pil/şarjlı pil yutulursa 2 saat içerisinde ağır içsel yanmaya neden olur ve ölüme neden olabilir. Bu nedenle yeni ve kullanılmış pilleri/şarjlı pilleri ve ürünü çocukların erişemeyeceği şekilde saklayın. Bir pilin/şarjlı pilin yutulduğundan veya farklı bir şekilde vücudunuza girdiğinden şüpheleniyorsanız, derhal tıbbi yardım isteyin.

Yaralanma tehlikeleri

- Uzun süre doğrudan ışığa bakmayın. Bu, gözlere hasar verebilir.
- Piller bölünmemeli, ateşe atılmamalı veya kısa devre yapılmamalıdır.
- Eğer bir pill akımsız asla cildinize, gözlerinize ve mukoza bölgelerine temas ettirmeyin. Gerekliğinde temas eden yerleri temiz suyla yıkayın ve hemen bir doktora başvurun.

Maddi hasarlar

- Pilleri aşırı ısıdan koruyun. Pillerin enerjisi azaldığında veya ürünü uzun süre kullanmayacaksanız pilleri üründen çıkarın. Bu sayede pillerin akması ile oluşabilecek hasarları önlemiş olursunuz.
- Daima tüm pilleri birlikte değiştirin. Eski ve yeni pilleri, farklı tip, marka ve kapasitedeki pilleri bir arada kullanmayın.
- Gerekliyorsa pilleri ve alet kontaklarını takmadan önce temizleyin. Aşırı ısınma tehlikesi!
- Pilleri yerleştirirken kutupların doğru olmasına (+/-) dikkat edin.
- Ürünü tozdan, nemden, doğrudan güneş ışınlarından ve aşırı sıcaklardan koruyun. Aşırı darbelerden ve çarpmalardan kaçının.
- Entegre edilmiş LED'ler değiştirilemez ve değiştirilmemelidir.
- Kredi kartları, banka kartları vb. gibi manyetik şeritli kartları mıknatıs tutucusundan uzak tutun. Manyetik şeritler hasar görebilir. Ayrıca manyetik bellekleri ve manyetizmadan etkilenebilecek veya fonksiyonu bozulabilecek tüm cihazları mıknatıs tutucusundan uzak tutun.
- Mıknatıs tutucusu, tesa® yapıştırma şeridi ile istenilen yere iyice yapışması için, alt taban yapıştırmadan önce kuru, tozdan, yağdan, silikondan ve kireçten arındırılmış olmalıdır. Alt taban ayrıca sağlam, düz ve yeterli derecede taşıma gücüne sahip olmalıdır. Düz olmayan ve pürüzlü yüzeyler alt taban olarak uygun değildir.
- Tesa® yapıştırma şeridi bir defalık kullanım için ön görülmüştür. 40 °C'den fazla sürekli olan sıcaklıklar tesa® yapıştırma şeridinin tutma gücünü azaltır. 15 °C'nin altındaki sıcaklıklar için tesa® yapıştırma şeridi uygun değildir.
- Bu tesa® yapışkan bantları yakl. 24 saat sonra tam yapıştırma kuvvetine ulaşır. Mıknatıs tutucusuna zamanından önce yüklenmeyin.
- Mıknatıs tutucusunu sabitleirken, LED çok fonksiyonlu lamba aşağıya düştüğünde hiçbir şeyin hasar görmemesine dikkat edin.

- Mıknatıs tutucusunu tekrar çıkarırsanız, alt tabanda yapıştırıcı kalıntılarının olabileceğini göz ardı etmeyin. Bunlar, çoğu zaman uygun ve düz alt tabanlardan parmaklar ile kazınabilir. Dikkate alınmalıdır: Boyanmış olan alt tabanlarda boya da çıkabilir!
- Temizleme için sert kimyasallar, tahriş edici ya da aşındırıcı temizlik maddeleri kullanılmamalıdır.


Teknik bilgiler

Model:	671 978
Piller:	3 adet LR6 (AA)/1,5V
Koruma sınıfı:	III
Algılama açısı:	yakl. 110°
Sensör etki mesafesi:	yakl. 3 m
Aydınlatma süresi:	yakl. 30 saniye
Ortam sıcaklığı:	+10 ila +40 °C
Tchibo için özel olarak üretilmiştir :	Tchibo GmbH, Überseering 18, 22297 Hamburg, Germany, www.tchibo.com.tr

Ürün geliştirmeleri çerçevesinde üründe teknik ve dizayn değişikliği yapma hakkımız saklıdır.



Pilleri yerleştirme/değiştirme




Pilin kutuplarına (+/-) dikkat edin.


LED lambanın takılması

Mıknatıs tutucuyu tesa® yapışkan bantla veya verilen cıvatalarla kolayca takabilirsiniz.

Yapıştırma




Vidalama




LED lambanın hizalanması

Çok fonksiyonlu LED lamba maks. 90° döndürülebilir. Lambayı, istenen alan en uygun halde aydınlatılacak şekilde hizalayın.




Çok fonksiyonlu LED lambada bir hareket sensörü bulunur. Hareket sensörü maks. 180° döndürülebilir.




Hareket sensörü

Hareket sensörünü ne kadar ileriye veya geriye çevirdiğinize bağlı olarak 110°'lik bir açıyla 3 m'ye kadar olan hareketleri algılayabilir ve ardından LED lambayı devreye alabilir.



Öneri: LED lambayı mıknatıs tutucudan çıkardığınızda el feneri olarak da kullanabilirsiniz.

Açma/kapama



- ON** = LED'ler sürekli açık.
- AUTO** = LED'ler yaklaşık 30 saniye sonra yanar ve hareket sensörü hiç bir hareket algılamadığı vakit otomatik olarak söner. Hareket sensörü tekrardan bir hareket algıladığında, LED'ler yeniden yaklaşık 30 saniye yanar.
- OFF** = LED'ler sürekli kapalı.

İmha etme

Ürün, ambalajı ve birlikte verilen piller, tekrar kullanılabilen değerli malzemelerden üretilmiştir. Tekrar kullanım sayesinde atıklar azalır ve çevre korunur.

Ambalajı malzeme türüne göre imha edin. Bunun için bölgenizdeki kağıt, mukavva ve hafif ambalaj toplama merkezlerinin sunduğu imkanlardan faydalanabilirsiniz.

Bu sembolle işaretlenen **cihazlar, piller** ve **şarjlı piller** ev atıkları ile birlikte atılmamalıdır! Yasalara göre atık cihazlarınızı, ev çöpünden ayrı atmak zorundasınız. Elektrikli cihazlar tehlikeli maddeler içerir. Bunların uygun olmayan şekilde depolanması ve imha edilmesi çevreye ve sağlığa zarar verebilmektedir. Atık cihazları ücretsiz olarak geri alan toplama merkezleri hakkında bilgi almak için bağlı bulunduğunuz belediyeye danışabilirsiniz.

Boş **pill**er ve **şarjlı pill**er bölgenizdeki belediye atık toplama yerlerine ya da pil satan yerlerdeki toplama kaplarına bırakılmalıdır. Lityum piller/şarjlı piller için, imha etmeden önce kontakları yapıştırın.



www.tchibo.com.tr/kilavuzlar

Ürün numarası: 671 978

Tchibo için özel olarak üretilmiştir:
Tchibo GmbH, Überseering 18, 22297 Hamburg, Germany, www.tchibo.com.tr