







1.

M2477_02













rauch













SK010 = SK020 = SK030 = SK040



2.

2x



3.

 <p>11</p>	<p>20x 18</p>  <p>8x30</p>	<p>20x 183</p>  <p>23/10x7,5/6,5</p>	
<p>6x 215</p>  <p>3x20</p>	<p>16x 227</p>  <p>6x10,5</p>	<p>8x 251</p>  <p>328x17x9,5</p>	
<p>20x 349</p> 	<p>8x 568</p>  <p>M4x9</p>	<p>12x 1090</p> 	<p>16x 1105</p> 

0 20 40 60 80 100 mm

M2477

4.







Diagram showing exploded view of components:

- BT020 (Top panel)
- RW010 (Right side panel)
- SE010 (Left side panel)
- WA010 (Shelf)
- B0010 (Shelf support)
- MS010 (Middle side panel)
- SE020 (Right side panel)
- BT010 (Bottom panel)
- FU010 (Fastener)
- ZA010 (Drawer front)
- SB010 (Drawer bottom)
- SK010 (Drawer side)


M2477

1

11




2





3

6x 183




23/10x7,5/6,5




4

12x 18





8x30



5


12x 349



9.

6

2x (251)




328x17x9,5


4x (227)




6x10,5



1. 227



2. 227




SE010

10.

7

2x (251)





328x17x9,5


4x (227)




6x10,5



1. 227



2. 227




SE020

11.

8

2x (251)





328x17x9,5


4x (227)




6x10,5



1. (227)




2. (227)



12.

9

2x (251)





328x17x9,5


4x (227)




6x10,5



1. (227)




2. (227)






13.

10

8x 183



23/10x7,5/6,5



M2477



14.

11

8x 18






8x30








12

8x 349








M2477



13




14




15



16







17





18

6x 183









19

12x 1090







Xmm = Xmm






20

6x 215






21

2x 1091




22

ø6mm



25.

23




M2477





26.

24

2x 1093




2x 1147




M2477


25




1.





2.





? 3.




26




1092



1093




10-15mm



1093

1092





27

8x 568








M4x9




28

16x 1105



MZ044_02



rauch




FU010

4x30


213




BT010



180°



BT010








1

8x

213

4x30





2

2x



213

4x30




MS010

BT010




FU010

1.



Xmm Xmm
Xmm Xmm




2.



213

FU010





3

2x




213

4x30




MS010

BT010




FU010




FU010

1.



Xmm Xmm
Xmm Xmm Xmm




?

2.



213

FU010








4

4x



213

4x30




MZ277_01


GR010



1.






2.





GR010


3.








Xmm=Xmm






1090




45




1090




45



1.



2.



3.